



**NOTES:**

1. THE CONTRACTOR IS REQUIRED TO INSTALL ONE CONTINUOUS #10 AWG SOLID COPPER UL/UF, RHW, OR RHH WIRE ALONG THE PIPE AND OUTSIDE THE VALVE RISER. SECURE WIRE(S) TO THE RISER AND PIPE PER THIS DETAIL.
2. THREAD #10 WIRE(S) THROUGH 1/2" HOLE. CONTRACTOR SHALL LEAVE A MINIMUM OF THREE FEET (3') OF NEW WIRE INSIDE OF RISER. EXCESS WIRE SHALL BE LEFT NEATLY AGAINST INSIDE OF RISER.
3. WHERE A SPLICE IS NECESSARY, USE UNDERGROUND SPLICE KIT OF #10 SILICONE-FILLED WIRE NUT.
4. MATERIAL FOR VALVE RISER SHALL BE PVC C-900 AND SHALL BE OF CONTINUOUS LENGTH TO THE BOTTOM OF THE VALVE BOX.

**TRACER WIRE & POLYETHYLENE WARNING TAPE**



ISSUED: 07/2014 SCALE: N.T.S.  
REVISED: 06/2016

PAGE 1 OF 1

S.D.# MW-116